



1. Application

Decor

KOMFORTEX[®] Decor is the ideal floor covering for stables run-out. With the attractive cobblestone optic will be the range of area design adjusted in accordance with good characteristics like joint-friendly and shock adsorbing. Integrated connector pins permit easy and cost-efficient installation a masonry-style configuration without need gluing bring a very good dimensional stability. Please note the special installation instruction!

Environmentally sound manufacturing (dual KRAIBURG Relastec GmbH & Co.KG Recycling guarantee) and recycling.

2. Material Rubber granulate: granulated recycled rubber Binding agent: polyurethane 3. Characteristics Colour: red Surface: smooth with open pores cobblestone optics Lower side: dimple textured 4. Dimensions / Tolerances L x W x T: 500 x 500 x 40 mm length, width: +/- 0,8 %, thickness: +/- 2 mm Tolerance: Area weight: approx. 36 kg/m² 5. Product testing Tensile strength: approx. 0,75 N/mm² EN-DIN-ISO 1798-2008 (DIN 5357) Elongation at break: approx. 70 % EN-DIN-ISO 1798-2008

Fire resistance:E(DIN 5357)Cold fracture resistance:24h / -40°C, no fracture(DIN EN 13501-1, 2007)Cold crack resistance:5h / -30°C, no cracks

All information without guarantee, subject to change. The Data Sheet is not subject to any change service. Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex











6. Installation

Pour level layer of lean concrete or crushed rock over frost-stable sub grade. If the surface covered is an existing concrete or asphalt surface, take care to provide sufficient slope for water drain-off and level off any irregularities with stone chippings (grain size 0-3 mm). Use edge slabs and corner slabs around the surface to minimize danger of stumbling. Cement these slabs to one another, to the KOMFORTEX® surface and if possible to the substructure. Install the slabs in a masonry-type configuration, i.e. beginning every second row with a half slab. Insert connector pins fully into the receiving holes. To ensure secure placement, cement the crosswise joints of the first and the last row. The cement should be an 1-component PU adhesive cement.

Cut slabs to size using a powered sabre saw.

Note the complete installation instruction.

All information without guarantee, subject to change. The Data Sheet is not subject to any change service. Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex

page 2 of 2





