

## 1. Substrate

All substrates made of asphalt, concrete and poured levelling screed are suitable for installation. The substrate must be solid, level, dry, clean and free of cracks, undulations and dust which can potentially affect adhesion.

**SPORTEC® edge- & corner ramps** should not be installed on loose or dynamic sub-bases. A solid base is required to ensure stability and performance.



Suitable, solid surface

## 2. Preparation Work


The surface of the substrate has to be brushed clean before starting installation. Minor unevenness must be levelled with a liquid self-leveler or filler compound

Remove the profiles from the pallet and lay down loose on the ground and store them in the area you want to install for about 1-2 days before installation to ensure correct acclimation.


The ambient temperature for installation of **SPORTEC® edge- & corner ramps** should be between 15 °C and 25 °C.

## 3. Installation

Lay the profiles on the edge of the **SPORTEC® style** or **SPORTEC® base** tiles and glue them. For installation of **SPORTEC® edge- & corner ramps**, an edging (L-section) of metal is necessary. Lay the edging directly below the tile and glue them with a 1-component PUR adhesive to the surface. An additional fixing of the profiles with dowels is recommended. The next step is to glue the **SPORTEC® edge- & corner ramps** to the edging and the surface and as well the joints between the profiles. With this procedure there will be a high safety against moving the tiles. The slabs are easy to cut by using a low-speed sabre (blade for wood/medium-size teeth) or a carpet knife in conjunction with a steel straightedge.



Installation of the profiles



Installation of L-section

#### 4. Coating

It is not recommended to apply a coating on the profiles in general.

The installation recommendation is not subject to any change service! All information is without guarantee.

Latest version of this document available on [www.kraiburg-relastec.com/sportec](http://www.kraiburg-relastec.com/sportec)

## 5. Important details

The profiles may only be installed on leveled, dry and clean substrate.

The profiles could be cut to size using an electric jigsaw or a sharp cutting knife.

It is possible to quickly and easily uninstall and store the profiles and then install again when needed.

Rubber products have an odour typical of the material, which decreases over time. This can be accelerated by regular airing.

**In case of claims caused of falsely delivered goods, defect goods, insufficient quantities or other possible faults stop the installation immediately and make a claim directly. A claim of delivered material is only possible with untreated and uninstalled material and with confirmation of the order number.**

### DISCLAIMER:

These recommendations for applications and installation are based on our extensive experience and on current technological practice. Our liability and responsibility in the event of damages shall be limited to the extent defined in our General Terms and Conditions of Business, regardless of the above recommendations or of any statements made or advice given by our sales representatives or applications engineering staff.