

Substructure

The substructure must be level. The slabs can be installed directly over firmly compacted aggregate substructures. Take care that the substructure is at the correct level (i.e. desired pavement surface level minus thickness of the installed slabs). The best substructure is a level bed of stone chippings (aggregate size: 0 – 7 mm) approx. 30 mm thick.

Please note our detailed descriptions of the preparation of the substrate in the installation instructions for the fall protection and sport pavement slabs.

Installation

When installing on a newly constructed playground prepare the substructure as described above. When installing on an existing playground, level out and compact any depressions formed under swings, seesaws, ends of slides etc.

To cover areas larger than 2 slabs, combine EUROFLEX® Protect slabs using the 3 connectors provided for each slab. Use 2 on each joint perpendicular to the stressed direction and 1 on each joint parallel to the stressed direction. Before joining apply polyurethane adhesive cement on mating surfaces. Put joined slabs in place on the prepared substructure. Take care that the substructure is at the correct level (i.e. level of surrounding lawn minus thickness of the installed slabs).



To avoid colour variations due to differences in sunlight exposure, leave the UV protection film on the product as supplied until just prior to installation.

All information without guarantee, subject to change. The installation instruction is not subject to any change service. Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex/