

Storage of KOMFORTEX® Products and adhesive cements

KOMFORTEX® products should normally be stored in dry areas at constant temperature above 10°C. If stored below 10°C, store the slabs at the installation site temperature (> 10°C) for at least 2 hours before installation.

Important note: Adhesive cements must be stored at all times in dry locations above 0°C. To avoid colour variations due to differences in sunlight exposure, leave the UV protection film on the products as supplied until just prior to installation.

Required Tools

Cut Cutting knife, heavy duty, with replacement blades, hand saw, sabre saw or band saw (with blades for wood), steel straight edge (e.g. carpenters square 600 mm)



Mark Chalk line with refill chalk, felt-tip markers (water –soluble) or chalk, tape measure or meter stick



Gluing Application gun for dispensing adhesive cement, adhesive cement cartridges, work glove, kneepads




All information without guarantee, subject to change. The Data Sheet is not subject to any change service. Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex


page 1 of 13

Preparation of Subsurface

1. Preparation of unbounded subgrade



2. Preparation of bounded subgrade



Note: The basement is take off until attended depth plus thickness of the slabs. Through acceptance inspection for the subgrade is recommended for installation the slabs.

Note: For the Slabs must be saving that, the subgrade is possible to absorption the water. The edge trim for the Slabs must be flexible like the KOMFORTEX® Softborder no concrete! KOMFORTEX® Slabs in 30mm thickness must be installing on a bonded subbase!

Subsurface Design / Acceptance Criteria

KOMFORTEX® slabs have excellent drainage properties. The subsurface below them must therefore provide sufficient drainage as well. Paved surfaces (such as concrete or asphalt) must be level with a slope of approx. 2% and have adequate takeoff drains.

Suitable materials must level off any depressions greater than 3 mm in depth, which can collect water.

Like other elastomeric materials, KOMFORTEX® products absorb heat when exposed to direct sunlight. Their surface temperatures can be higher than asphalt surfaces exposed to the same conditions. KOMFORTEX® products should be installed and stored in shady areas if possible to avoid overheating.

Preparation of the Subsurface

Proper construction and acceptance inspection of this subsurface before installation is extremely important.

The following instructions must be followed exactly by the contractor carrying out the subsurface preparation and by the KOMFORTEX® slab installer in subsequent acceptance inspection. Remove the existing soil to a depth of min 300 mm plus the thickness of the slabs that will be installed.

If no edge trim enclosed is present around the area to be covered, install KOMFORTEX® Lawn Edging for safer playing conditions.

KOMFORTEX® slabs are elastic products with open pores. Based on optional effects of the weather, as much rain, it is possible that the dimensions change.

Should questions arise regarding soil conditions and characteristics or expected soil behavior, consult a soil mechanics engineer.

Compact each layer with a vibration compactor to 98% standard Proctor density.

Following application of the final layer, again check levelness, correct uneven spots with suitable material. Paved subsurface such as concrete or asphalt must be absolutely even level without any vertical height. To avoid water collection, must have a slope of at least 2 % and must lead into a take-off drain system.

The surfaces must be free of cracks, clean and free of oil or other foreign materials. Regardless of the type of subsurface used; it must not deviate from level by more than 5 mm under a 3 m lathe.



Crushed stones, Grain Size 0-32 mm



firmly compacted



Crushed sand/stone chippings 0/5mm, 0/8mm or comparable even and flat, firmly compacted

Perpendicularity Check, Minimization of Dimensional Variations

Start installation by laying a chalk line parallel to and a full slab width away from one side of the surface to be covered. Lay a second chalk line exactly perpendicular (at an angle of 90°) to the first. Check that the lines are perpendicular by the 3/4/5 rule: Starting at the intersection point of the lines, measure off exactly 3 m down the first line, mark this point, then measure off exactly 4 m down the second line, and mark this point. Measure the distance between the two points marked. If the lines are perpendicular, the distance between the points will exactly be 5 m.

The dimensional tolerance of KOMFORTEX® slabs as manufactured is approx. +/- 0,8% in length and width, +/- 2 mm thickness. Dimensional variations can be caused by storage in stacks (elastic compression of the slabs due to the stack weight) and changes in thermal expansion and ambient temperature.

All information without guarantee, subject to change. The Data Sheet is not subject to any change service. Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex

The following procedures are recommend to minimize dimensional variations:

- Be certain that all slabs to laid have the same temperature over the entire term of installation.
- Spread the slabs out on the ground for 2 hours before final installation to permit them to regain their original dimensions.
- Install all slabs in a single session to ensure installation under similar conditions.

For ideal installation conditions, the ambient temperature at the site should have been over 4°C for at least 24 hours prior to installation. If the ambient temperature at the site is below 4°C, store the slabs to install in a dry area at a temperature of at least 10°C for at least 72 hours prior to installation.


Do not install KOMFORTEX® slabs if ambient temperatures below 4°C is expect at the installation site for an extended period.

Installation of KOMFORTEX® Slabs


Install the first row of KOMFORTEX® slabs by placing them precisely along the chalk line (During installation of the Sports Pavement Slabs with synthetic turf, please make certain that the blades of grass or tufting for each tile are aligned in the same direction. Doing so will provide a uniform optical appearance across the entire surface.

Start the second row (and every second row thereafter) with a half slab. Connect the slabs of the second row to the first by the integrated connector pins. The masonry-style configuration (Figure 1) provides stability of the installed slabs. Cut the last slab in each row to the required size using a heavy-duty carpet knife or a sabre saw.


Correct: „T“-joints



**Incorrect: „T“-joints
Installed in line**




Incorrect: cross joints



All information without guarantee, subject to change. The Data Sheet is not subject to any change service.
Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex



For installation the slabs as way area or comparable, should use the following installation direction:



Glue only slabs of the first and the last row and all slabs on the outer perimeter to each other and to the edge limitation enclosing the surface (if it is an unbounded surface like concrete) to secure them against uplifting or unauthorized removal.

Read the use instructions for the adhesive cement carefully prior the installation. Use only adhesive cements which supplied or recommend by KRAIBURG Relastec GmbH & Co. KG. Suitable disposable gloves should worn during glue application to avoid skin irritation.

All information without guarantee, subject to change. The Data Sheet is not subject to any change service. Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex

Attention!

To get the right H Paver layout please follow the instruction:

- 1. Row



- 2. Row and every second row following




All information without guarantee, subject to change. The Data Sheet is not subject to any change service.
Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex

page 7 of 13

- 3. Row



- 4. Row



All information without guarantee, subject to change. The Data Sheet is not subject to any change service.
Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex

page 8 of 13



Attention: At installation slabs on bonded subgrade, concrete or asphalt, are a down grade approx. 2% and a free drainage always necessary. It must be sure that the slabs not any wetness absorb at the subgrade. The result would be that the slabs expanded and displace.

Cutting slabs with a stable cutter knife

- Measure and mark cutting edge



- Cutting with cutter knife



All information without guarantee, subject to change. The Data Sheet is not subject to any change service. Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex



Or with a pad saw, saw blade for wood

Mark the relief



All information without guarantee, subject to change. The Data Sheet is not subject to any change service.
Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex

page 10 of 13

KOMFORTEX® elastic slabs can also use for indoor stable aisles. The subsurface should be even, with a gradient of 1-2% and a corresponding drainage.



All information without guarantee, subject to change. The Data Sheet is not subject to any change service.
Each current and valid from can be recalled at www.kraiburg-relastec.com/euroflex

page 11 of 13

Maintenance of the Installed KOMFORTEX® Surface

Regular cleaning of your installed KOMFORTEX® surface will promote a long useful life as well as attractive appearance. KOMFORTEX® surfaces can be kept clean by sweeping with a soft-bristled broom or vacuuming with an industrial vacuum cleaner. High-pressure water spraying can also be used to clean KOMFORTEX® surfaces and provides more efficient dirt removal from the surface pores of the slabs.

KOMFORTEX® slabs are not adversely affected by cleaning with most common household or industrial cleaners when diluted in accordance with manufacturer's recommendations. Light surface stains can be removed with such cleaners using a scrubber or a cleaning rag. Depending on the frequency of use, KOMFORTEX® surfaces will occasionally need deep cleaning procedures to remove dirt, stains, mold and mildew, etc. These procedures utilize a steam cleaner or power washing with or without the use of cleaning agents. Cleaning the gaps between the slabs is very important.

Please note: Out KOMFORTEX® warranty is not applicable if the product has not been maintained in accordance to out maintenance instructions above.

Gluing instruction



It is recommended to glue the edge and corner profile extra to the subbase and glue them holohedral to the subbase.

The profile must be glued to the first line of slabs.



Required quantity of glue: 1 cartridge (310 ml) for every 3 – 4 m of joint length glued.

Type of glue: elastic 1-component polyurethane adhesive cement Ottocoll P 83 grey and Ottocoll M 500 red can be obtained from us.

Preparation: The surfaces must be clean, dry and free of grease. Check adhesion to and compatibility with plastic and painted surfaces before installation.

Gluing: Apply adhesive cement from application pistol onto the substrate. The required layer thickness is dependent on the materials being joined. Within 10 minutes, put the upper material in place and apply contact pressure. Due to the pasty consistency of the cement, we recommend maintaining contact pressure until curing is complete. The required curing time is dependent on the layer thickness and the humidity of the ambient air.

Processing temperature: + 5°C until +40°C

Film after 20 min at 23°C

Curing time after 24 h at 23°C